

## TECHNICAL DATA SHEET

### ARDON S3 SRC

#### Safety shoes

Article NO: G1055

Upper: buffalo leather - full grain  
Liner: non-woven fabric TAIBRELLE  
Sole: PU2D  
Description: full-leather high shoes  
steel toecap  
reflective stripe



Size: 36 - 48

PU2D sole is antiwriting, resistant to oils and fuels and contact heat up to 110°C. It is antistatic and absorbs shocks up to 20 J in the heel area. Design of the sole provides high adhesion to the surface and the profile significantly reduce the risk of slip. Wide comfort sole with toecap of width 522 reduces the feeling of tiredness and eliminates galls in fingers area.

This shoes are suitable for use at construction works.

#### Type and degree of protection:

Category	EN ISO 20345
Antistatic properties	x
Absorption of energy in the heel area	x
Sole with pattern- oil resistance	x
Water resistance	x
Puncture resistance (steel insole)	x
Safety toecap for toe protection	x
Slip resistant ceramic tile floor with SLS and on steel floor with glycerol (SRC)	x



This personal protective equipment is in conformity with this harmonized European Standard:

EN 20345:2011 : Personal protective equipment - safety shoes.



Certified by notified body no. 0362

(ITS Testing Services (UK) Ltd, Centre court, Meridian Business Park, Leicester LE19 1WD, UK), Certificate number LECFI00373176.

---

Pairs in carton:	10
Carton weight:	15,5 kg
Carton size:	0,095 m <sup>3</sup>

---

The shoes have to be perfect as for form and size, because they have rigid parts. The right size has to be found by measuring practically and carefully the shoes. The closing system has to be used correctly. The laces have to be tightened well without leaving too long free tops. The shoes have to be cleaned and treated with right, specific products, following the instructions for use. Do not keep footwear near heatings when not used and let them dry in a windy or room temperature. Before wearing and when cleaned, the shoes have to be controlled in order to find out visible defects existing, like closing system function, outsole profile's wear, possible damages, etc. To define the right type of footwear to wear in every environment, the possible dangers and the place/ environment have to be considered (e.g. construction industry, high temperatures, etc.). The shoes have to be stored correctly, keeping them in the proper packing.