

TECHNICAL DATA SHEET

FIRWIN S3 SRA

Safety shoes

Article NO: G3131

Upper: buffalo leather
 Liner: synthetic fur, foam
 Sole: PU2D
 Description: full-leather high shoes
 steel toecap and midplate
 water resistance, with fur lining



Size: 36 - 50

PU2D sole is antiwriting, resistant to oils and fuels and contact heat up to 110°C. It is antistatic and absorbs shocks up to 20 J in the heel area. Design of the sole provides high adhesion to the surface.

This shoes are suitable for use at building and heavy engineering.

Type and degree of protection:

| Category | EN ISO 20345 |
|--|--------------|
| Antistatic properties | x |
| Absorption of energy in the heel area | x |
| Sole with pattern- oil resistance | x |
| Water resistance | x |
| Slip resistance on ceramic tile floor with SLS (SRA mark). | x |



This personal protective equipment is in conformity with this harmonized European Standard:

EN ISO 20345:2011 - Personal protective equipment - safety shoes.
 Slip resistance on ceramic tile floor with SLS (SRA mark).

Certified by notified body no. 2369 (VIPO, Slovakia),
 Certificate number 00125/111/1/2018.



| | |
|--------------------|----------------------|
| Pairs in carton: | 10 |
| Carton weight: | 19 kg |
| Carton size: | 0,108 m ³ |
| Country of origin: | China |

The shoes have to be perfect as for form and size, because they have rigid parts. The right size has to be found by measuring practically and carefully the shoes. The closing system has to be used correctly. The laces have to be tightened well without leaving too long free tops. The shoes have to be cleaned and treated with right, specific products, following the instructions for use. Do not keep footwear near heatings when not used and let them dry in a windy or room temperature. Before wearing and when cleaned, the shoes have to be controlled in order to find out visible defects existing, like closing system function, outsole profile's water, possible damages, etc. To define the right type of footwear to wear in every environment, the possible dangers and the place/ environment have to be included (e.g. construction industry, high temperatures, etc.). The shoes have to be stored correctly, keeping them in the proper packing.
